



Canon ZR-20 Mini-DV Digital Camcorder

This small digital video camera recorder can be used to record classroom activities or other events. It includes an AC adaptor (recommended), battery pack (lasts about 1 hr.), remote control, AV cables, battery charger and carrying case. A small TV/VCR can be used as a monitor and for recording video and sound output from the camera. This camera uses the Mini-DV format videotape to store recordings.



Sony Handycam DCR-TRV33 Camcorder

This small digital video camera recorder can be used to record classroom activities or other events. It includes an AC adaptor (recommended), battery pack (lasts about 1 hr.), remote control, 128 MB memory stick (for still pictures), AV and USB cables, and carrying case. A small TV/VCR can be used as a monitor and for recording video and sound output from the camera, or the camera can be directly connected to a computer via the USB cable. This camera uses the Mini-DV format videotape to store recordings.



Sony Handycam DCR-SR40 HDD Camcorder

This small digital video camera recorder can be used to record classroom activities or other events. It includes an AC adaptor (recommended), battery pack (lasts about 2 hrs.), AV and USB cables, and carrying case. A small TV/VCR can be used as a monitor and for recording video and sound output from the camera, or the camera can be directly connected to a computer via the USB cable. This camera has an internal hard drive to store video; no tapes are required.



Kodak EasyShare DX7630 Digital Still Camera

This digital still camera can be used to take still digital photographs of people, objects, or scenery. Features include up to 6.1 megapixel resolution, 3x optical zoom lens, 32 Mb internal memory, and short video recording capability. It includes an AC adaptor, battery pack (allows for approx. 325 pictures), A/V and USB cables, and carrying case. The camera can be directly connected to a computer via the USB cable.