



### **Eike 7070A Combination CD/Cassette Deck**

This medium- sized unit can play audio CD's or cassettes. Has 1/4" jacks available for external speakers or up to 5 headphones. Can record on standard cassette tape with external microphone (not included). AC power cord included -- not battery operated.



### **Eike 3279A Portable Cassette Deck**

This portable audio cassette recorder/player has plug-ins for microphone, remote, and auxiliary. Also has 1/4 in. plug-ins for 4 headphones. Battery compartment takes six C-sized batteries or can be plugged into wall outlet via AC power cord.