



### **Magnavox MSC804 Combination VHS/DVD Player**

This combination VCR/DVD player plays VHS videotapes, DVDs, DVD-Rs, CDs, CD-Rs, CD-RWs, Video CDs, and MP3 discs.

Comes with full function remote control, coax cable, and tri-colored RCA cables. Can be connected to any television with a standard 75 ohm (coax) input or RCA audio/video inputs.



### **Samsung DVD-P230 DVD Player**

Plays DVDs, DVD-Rs, CDs, CD-Rs, CD-RWs, Video CDs, and MP3 discs.

Includes full-function remote control and tri-colored cable. For display or sound, unit must be connected to a television with RCA audio/video inputs using the tri-colored cable (included).



### **Toshiba SD-1810 DVD Player**

Plays DVDs, DVD-Rs, CDs, CD-Rs, CD-RWs, Video CDs, and MP3 discs.

Includes full-function remote control and tri-colored cable. For display or sound, unit must be connected to a television with RCA audio/video inputs using the tri-colored cable (included).



### **Orion VR-313A VHS Videocassette Recorder**

Videocassette recorder/ player for use with standard VHS videocassette tapes. Includes remote control and A/V RCA cables. Can be connected to any television with a standard 75 ohm (coax) input or RCA audio/video inputs.